

Lexus Audio System Features






Lexus audio systems include advanced features that allow you to integrate, access and control your personal audio devices.

Using the USB Port




You can use the USB port to connect USB devices, such as an iPod or iPhone, or other USB memory devices.

- To connect an iPod or other USB device to the audio system, locate the USB port in the center console, plug the device in using the appropriate cable and turn it on.
 - Note that the current RX includes extension cables for both the USB port and 12-volt power.

Vehicles with Navigation

- Once the device is connected and activated, the “USB” tab  on the audio screen becomes active.
- To select this input as the audio source, select the “USB” tab  on the screen, or press the “CD-AUX” button  on the audio unit. The current track name, album title and artist name will be displayed on the audio screen.
- When using a playback device connected through the USB port, you can control it through the vehicle’s audio system control panel.
- The “SELECT” button  on the audio screen allows you to jump to a specific track.
- To browse all tracks on your device, press the “MENU” button . You’ll see several tabs to sort the tracks by PLAYLISTS, ARTISTS, ALBUMS, SONGS, PODCASTS, AUDIOBOOKS, GENRES, or COMPOSERS. Select one of the tracks on any tab to begin playback. Press the “BACK” button to return to the “USB” tab.
- Buttons at the bottom of the audio screen allow you to pause playback, repeat current track, randomize all tracks, or adjust sound and tone settings.

Vehicles without Navigation



- Once the device is connected and activated, you can select this input as the audio source by pressing the “CD-AUX” button  on the audio unit. The current track name, album title and artist name will be displayed on audio unit screen.
- When using a playback device connected through the USB port, you can control it through the vehicle’s audio system controls.
- To select a playback mode, press the “TUNE-FILE” button  to select the device menu.
- Turning the “TUNE-FILE” button  changes the play mode in the following order: PLAYLISTS, ARTISTS, ALBUMS, SONGS, PODCASTS, GENRES, COMPOSERS, or AUDIOBOOKS. Select one of the play modes to begin playback.
- Use the audio system control buttons to pause playback, repeat a track, shuffle all tracks, or adjust sound and tone settings.

Using the AUX Jack


The Auxiliary Input jack allows you to connect an iPod or other audio device to the audio system.

- Plug your device into the Auxiliary Input jack using an eighth-inch mini plug. The input is usually located on or inside the center console.
 - Note that the current RX includes extension cables for both the USB port and 12-volt power.

Vehicles with Navigation

- Once the device is connected and activated, you'll notice that the "AUX" tab  on the audio screen becomes available. To select this input as the audio source, press the "MODE" button on the steering wheel, the "AUX" tab on the screen, or use the "AUX" button  on the audio unit.
- Use the controls on your audio device to control playback. This is especially handy when listening to audio books.

Vehicles without Navigation



- Once the device is connected and activated, you can select this input as the audio source by pressing the "MODE" button on the steering wheel, or "AUX" button  on the audio unit.
- Use the controls on your audio device to control playback. This is especially handy when listening to audio books.

Note: Accessing USB/AUX Ports and 12-Volt Power in RX Models

In current RX models, the USB port, Auxiliary Input jack and 12-volt power outlet are located in the center console, underneath the storage bin. To access the USB/AUX port or power outlet, you must first remove the storage bin. Extension cables have been provided that, once installed, allow you to connect devices without removing the storage bin.

Programming Radio Presets with Remote Touch



To program radio presets on vehicles equipped with Remote Touch, follow these steps:

- Select the "AM", "FM" or "SAT" screen tab .
- Tune in the desired channel using the "TUNE-FILE" knob .
- Use the Remote Touch to select the preset position you want and hold until a beep is heard.


Displaying Satellite Radio Text Information.

Pressing the "TEXT" button  while listening to XM[®] Radio displays the song or program title and the artist name or feature.

Vehicles with Navigation

- Touch  to display the song/program title and the artist name/feature.
- Touch  again to return to the previous display.

Vehicles without Navigation

- Press the "TEXT" button .
- The display changes as follows each time the button is pressed:
 - "CH NAME"
 - "TITLE" (SONG/PROGRAM TITLE)
 - "NAME" (ARTIST NAME/FEATURE)
 - "CH NUMBER"

For Additional Information on Lexus and Your Vehicle

- Contact your dealership.
- Go to www.lexus.com.
- Official Lexus Site: www.mylexus.com
Here you can access specific information about your Lexus, including instructional videos (info available for all models).
- YouTube: www.lexus.com/tutorials
Here you will find Lexus "Quick Guide" videos.
- Lexus App: www.lexus.com/app
Instructions on how to download the Lexus Enform[®] mobile application at your mobile app store to reach these tutorials through your mobile device (e.g., Smartphone).